



Installing the Dell™ PowerEdge™ R610 Server

03-603793
Issue 1
November 2010

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on its Hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support Web site: <http://support.avaya.com>. Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/](http://support.avaya.com/licenseinfo/) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Avaya grants End User a license within the scope of the license types described below. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a

different number of licenses or units of capacity is specified in the Documentation or other materials available to End User. "Designated Processor" means a single stand-alone computing device. "Server" means a Designated Processor that hosts a software application to be accessed by multiple users. "Software" means the computer programs in object code, originally licensed by Avaya and ultimately utilized by End User, whether as stand-alone Products or pre-installed on Hardware. "Hardware" means the standard hardware originally sold by Avaya and ultimately utilized by End User.

License types

Designated System(s) License (DS). End User may install and use each copy of the Software on only one Designated Processor, unless a different number of Designated Processors is indicated in the Documentation or other materials available to End User. Avaya may require the Designated Processor(s) to be identified by type, serial number, feature key, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Concurrent User License (CU). End User may install and use the Software on multiple Designated Processors or one or more Servers, so long as only the licensed number of Units are accessing and using the Software at any given time. A "Unit" means the unit on which Avaya, at its sole discretion, bases the pricing of its licenses and can be, without limitation, an agent, port or user, an e-mail or voice mail account in the name of a person or corporate function (e.g., webmaster or helpdesk), or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software. Units may be linked to a specific, identified Server.

Database License (DL). End User may install and use each copy of the Software on one Server or on multiple Servers provided that each of the Servers on which the Software is installed communicate with no more than a single instance of the same database.

CPU License (CP). End User may install and use each copy of the Software on a number of Servers up to the number indicated by Avaya provided that the performance capacity of the Server(s) does not exceed the performance capacity specified for the Software. End User may not re-install or operate the Software on Server(s) with a larger performance capacity without Avaya's prior consent and payment of an upgrade fee.

Named User License (NU). End User may: (i) install and use the Software on a single Designated Processor or Server per authorized Named User (defined below); or (ii) install and use the Software on a Server so long as only authorized Named Users access and use the Software. "Named User", means a user or device that has been expressly authorized by Avaya to access and use the Software. At Avaya's sole discretion, a "Named User" may be, without limitation, designated by name, corporate function (e.g., webmaster or helpdesk), an e-mail or voice mail account in the name of a person or corporate function, or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software.

Shrinkwrap License (SR). Customer may install and use the Software in accordance with the terms and conditions of the applicable license agreements, such as "shrinkwrap" or "clickthrough" license accompanying or applicable to the Software ("Shrinkwrap License"). (see "Third-party Components" for more information).

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or Hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without

the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third-party components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

Preventing Toll Fraud

"Toll fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud Intervention

If you suspect that you are being victimized by Toll Fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support Web site: <http://support.avaya.com>. Suspected security vulnerabilities with Avaya products should be reported to Avaya by sending mail to: securityalerts@avaya.com.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners, and "Linux" is a registered trademark of Linus Torvalds.

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support Web site: <http://support.avaya.com>.

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your Product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://support.avaya.com>.

Contents

Chapter 1: Installing the Dell™ PowerEdge™ R610 Server	7
Dell R610 Server overview.....	7
How to use this document.....	7
Downloading Dell documentation.....	7
Dell R610 documentation set.....	8
Front view of Dell R610 Server.....	9
Back view of Dell R610 Server.....	10
Dell R610 Server specifications.....	11
Dell R610 Server power specifications.....	12
Dell R610 Server environmental specifications.....	13
Dell R610 Server physical specifications.....	13
Installing the server in the rack.....	14
Index	17

Chapter 1: Installing the Dell™ PowerEdge™ R610 Server

Dell R610 Server overview

The Avaya Common Servers category includes the Dell™ PowerEdge™ R610 1U server that supports several Avaya software solutions, some requiring additional hardware and memory requirements beyond the standard configuration. This book covers the standard configuration only—consult specific Avaya product documentation for application-specific or solution-specific server configurations.

How to use this document

This guide contains information for installing the Dell™ PowerEdge™ R610 Server as part of an Avaya deployment and provides:

- Instructions for how to find the appropriate online server documentation from Dell
- References to specific topics in standard Dell documentation
- Suggested changes, details, and notes to assist the user in interpreting the manufacturer's documentation and to clarify Avaya's recommended implementation of the equipment
- Additional topics not covered in standard Dell documentation but which are necessary for successful installation and maintenance of Avaya products

Downloading Dell documentation

Use this procedure to find and download the Dell™ PowerEdge™ R610 documentation from Dell.

Procedure

1. Open a browser and to go <http://www.support.dell.com/>.

2. On the Welcome to Dell Support page click on the *Start Here* button in the Support for Enterprise IT section.
 3. On the Welcome to Enterprise IT Support click on *Select a product* in the Product Support section.
 4. On the next page click on *Select Model* in the Choose a Model section.
 5. On the Select Product by Model page, click on *Servers, Storage, Networking*.
 6. On the Select Product by Model > Server, Storage, Networking page use the scroll bar in the Select Your Product Line column and click on *PowerEdge Server*.
 7. On the Select Product by Model > Server, Storage, Networking > PowerEdge Server page, use the scroll bar in the Select Your Product Model column and click on *R610*.
 8. On the Select Product by Model > Server, Storage, Networking > PowerEdge Server > R610 page, click on the *Confirm* button in the Confirm your selection section.
 9. On the Product Support for PowerEdge R610 page click on *Manuals and Documentation*.
 10. On the Dell™ PowerEdge™ R610 System page, click the *Download* link that corresponds to the document that you want to download.
 11. Download the documents in the *Dell R610 document set > Documents to download* section below.
-

Dell R610 documentation set

Refer to the documents listed below for Dell R610 server installation information and procedures.



Note:

Download the documents listed in the *Documents to download* section below. Printed copies of the documents listed in the *Documents included in the shipping container* section below ship with the server.

Documents to download

Abbreviation	Title	Part number
CMAI	Cable Management Arm Installation	0F880KA00
GS	Getting Started With Your System	R465D

Abbreviation	Title	Part number
HOM	Hardware Owner's Manual	No number
RI-SR	Rack Installation (Sliding Rails)	0J171KA00

*** Note:**

If you want to locate and download an individual document:

- Go to <http://www.dell.com/>.
- Type R610 plus the keywords of the document title in the Search field in the upper-right corner and press Enter.


Examples:

- Type R610 Technical Guidebook to search for the *Technical Guidebook* document.
- Type R610 Getting Started to search for the *Getting Started with your System* document.

Documents included in the shipping container

Abbreviation	Title	Part number
PS	Product Safety, EMC & Environmental Datasheet	No number
TG	Technical Guidebook	No number

Front view of Dell R610 Server




*** Note:**



Servers ship with 2–4 hard disk drives, depending upon product requirements.

No.	Description
1	power button
2	NMI button

No.	Description
3	USB connectors (2)
4	Video connector
5	LCD menu buttons
6	LCD panel
7	System identification button
8	Hard drives (maximum 4)
9	DVD-RW
10	System identification panel

Back view of Dell R610 Server



No.	Description
1	iDRAC6 Enterprise port (optional)
2	VFlash media slot (optional)
3	Serial connector
4	PCIe slot 1  Note: Servers might ship with a PCI card installed, depending upon product requirements.
5	Video connector
6	USB connectors (2)
7	PCIe slot 2  Note: Servers might ship with a PCI card installed, depending upon product requirements.
8	Ethernet connectors (4)
9	System status indicator connector

No.	Description
10	System status indicator
11	System identification button
12	Power supply 1 (PS1)
13	Power supply 2 (PS2)

Dell R610 Server specifications



Base unit	Baseline	Options
R610	1U chassis, dual socket	Listed below
Processor	Intel E5620 quad core /2.4 GHz (Westmere). For optimum performance, add memory in sets of three. 3 memory channels per CPU with up to 2 DIMMs per channel.	<ul style="list-style-type: none"> Intel X5670 six core/2.93 GHz (Westmere) Upgradable to dual processors for either E5620 or X5670
Memory	2 GB DDR3 RDIMMs (1333 MHz); up to 12 GB per processor using 2 GB DIMMs	4 GB DDR3 RDIMMs (1333 MHz); up to 24 GB per processor
HW RAID 1	H700 RAID controller with 512MB cache and battery backup. Optioned as RAID 1, 5, or 10.	For reduced cost replace H700 with H200. Most applications are RAID 1 (H200 supports RAID 0, 1 or 10 only).
Hot-Plug disk drive cage	6 small form factor 2.5" hot-plug hard drives bays included in base unit	N/A
Disk drive	146GB SAS 2.5" 10K RPM 6G DP Hard Drive. Two base configurations: <ul style="list-style-type: none"> 136 total: RAID 1, 2 x 146GB drives 272 total: RAID 5, 3 x 146GB drives 	Options: <ul style="list-style-type: none"> Additional 146GB 10K RPM drive (4 max. with optical drive) High performance 146GB 15K drives 600 GB 10K drives
NICs	4 integrated ENET gigabit NIC ports with TCP offload engine (included on motherboard)	Broadcom 5709 Dual Port 1GbE NIC (430-3261)

Base unit	Baseline	Options
PCI slots	2 PCIe risers (left and center) provide: <ul style="list-style-type: none"> • Two x 8 PCIe Gen2 slots • One x 4 PCIe Gen 1 slot • FH/HL PCIe card support 	No additional options supported.
Removable media	DVD+/-RW SATA internal	No additional options supported.
Power supply	<ul style="list-style-type: none"> • Single hot plug AC power supply • 502 W Hotplug AC power supply 	<ul style="list-style-type: none"> • 717 W AC power supply (required for dual X5670 processors) • Redundant supply available for either 502 W or 717 W.
Fans	Redundant Speed Adjusting Fans standard (5 for single processor)	No additional options supported. (2nd processor includes 1 additional fan)
Additional items	2 front USB, 2 back USB, 1 internal USB	

Dell R610 Server power specifications

Specification	Value
BTU	2446
Voltage	120 VAC
Plug Type	NEMA 5–15P
Circuit Breaker	15 amp
Pole	1
AMP Draw	6

Dell R610 Server environmental specifications

Specification	Value
Temperature	
Operating	10° to 35°C (50° to 95°F) with a maximum temperature gradation of 10°C per hour  Note: For altitudes above 2,950 feet, the maximum operating temperature is de-rated 1°F per 550 ft.
Storage	-40° to 65°C (-40° to 149°F) with a maximum temperature gradation of 20°C per hour
Relative Humidity	
Operating	20% to 80% (non-condensing) with a maximum humidity gradation of 10% per hour
Storage	5% to 95% (non-condensing) with a maximum humidity gradation of 10% per hour
Altitude	
Operating	-16 to 3,048 m (-50 to 10,000 ft.)  Note: For altitudes above 2,950 ft, the maximum operating temperature is de-rated 1°F per 550 ft.
Storage	-16 to 10,600 m (-50 to 35,000 ft.)

Dell R610 Server physical specifications

Type	Description
Dimensions	Height: 4.26 cm (1.68 in)
	Width: <ul style="list-style-type: none"> • 48.24 cm (18.99 in) with rack latches • 42.4 cm (16.99 in) without rack latches

Type	Description
	Depth: <ul style="list-style-type: none"> • 77.2 cm (30.39 in) with power supplies and bezel • 73.73 cm (29.02 in) without power supplies and bezel
Weight (maximum configuration)	17.69 kg (39 lb)
Weight (empty)	13.25 kg (29.2 lb)

Installing the server in the rack


This installation checklist contains the principle steps that are necessary to install the server in the rack. Each task refers to an existing Dell document and the topic title(s) that contains the step-by-step procedures. Where applicable, additional information and clarifications appear in the *Avaya recommendation* column. Perform each task in the order specified.



Note:

Although not used frequently, Avaya customers are required to have a monitor, keyboard, and mouse available for use by installation and/or servicing technicians.

No.	Task	Reference	Avaya recommendation	✓
1	Observe safety warnings.	PS RI-SR		
2	Examine contents of shipping container (Avaya provided equipment).		Ensure that the 6-digit material code on the order matches the 6-digit material code on the shipping container.	
3	Verify that the rack is installed according to the manufacturer's instructions and in accordance with all local codes and laws.			
4	Examine installation environment (customer provided equipment).			

No.	Task	Reference	Avaya recommendation	✓
5	Verify that the rack is grounded in accordance with local electrical code.			
6	Remove the cabinet doors, if necessary.			
7	Attach the rails to the rack	RI-SR: <i>Installing and Removing the Rails</i>	<p>The rails included with the server will accommodate most square-hole racks. If these rails do not fit the rack, the customer must provide rails or a shelf for rack installation. Also, the rails included with the server might not work with round-hole racks, in which case the customer can obtain rails and/or a shelf from any distributor, for example http://www.racksolutions.com/. The customer-provided rails and rack must be on site prior to the first day of installation.</p> <p> Note: The customer is responsible for any rack screws.</p>	
8	Attach the server to the rack.	RI-SR: <i>Installing the System in the Rack</i>		
9	(Optional) Install the cable management arm.	CMAI RI-SR: <i>Routing the Cables</i>		
10	Connect the power cord(s).	GS: <i>Connecting the Power Cables</i> GS: <i>Securing the Power Cord</i>		
11	Power up the server.	GS: <i>Turning on the System</i>		

Index

C	
checklist	14
installation	14
D	
Dell R610	9
front view	9
Dell R610 Server	7 , 10–13
back view	10
baseline specifications, configuration, and options	11
electrical specifications	12
environmental specifications	13
overview	7
physical specifications	13
power specifications	12
documentation	7 , 8
document set	8
downloading	7
how to use this document	7

