



Installing the HP DL360 G7 Server

03-603799
Issue 1
November 2010

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on its Hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support Web site: <http://support.avaya.com>. Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/](http://support.avaya.com/licenseinfo/) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Avaya grants End User a license within the scope of the license types described below. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a

different number of licenses or units of capacity is specified in the Documentation or other materials available to End User. "Designated Processor" means a single stand-alone computing device. "Server" means a Designated Processor that hosts a software application to be accessed by multiple users. "Software" means the computer programs in object code, originally licensed by Avaya and ultimately utilized by End User, whether as stand-alone Products or pre-installed on Hardware. "Hardware" means the standard hardware originally sold by Avaya and ultimately utilized by End User.

License types

Designated System(s) License (DS). End User may install and use each copy of the Software on only one Designated Processor, unless a different number of Designated Processors is indicated in the Documentation or other materials available to End User. Avaya may require the Designated Processor(s) to be identified by type, serial number, feature key, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Concurrent User License (CU). End User may install and use the Software on multiple Designated Processors or one or more Servers, so long as only the licensed number of Units are accessing and using the Software at any given time. A "Unit" means the unit on which Avaya, at its sole discretion, bases the pricing of its licenses and can be, without limitation, an agent, port or user, an e-mail or voice mail account in the name of a person or corporate function (e.g., webmaster or helpdesk), or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software. Units may be linked to a specific, identified Server.

Database License (DL). End User may install and use each copy of the Software on one Server or on multiple Servers provided that each of the Servers on which the Software is installed communicate with no more than a single instance of the same database.

CPU License (CP). End User may install and use each copy of the Software on a number of Servers up to the number indicated by Avaya provided that the performance capacity of the Server(s) does not exceed the performance capacity specified for the Software. End User may not re-install or operate the Software on Server(s) with a larger performance capacity without Avaya's prior consent and payment of an upgrade fee.

Named User License (NU). End User may: (i) install and use the Software on a single Designated Processor or Server per authorized Named User (defined below); or (ii) install and use the Software on a Server so long as only authorized Named Users access and use the Software. "Named User", means a user or device that has been expressly authorized by Avaya to access and use the Software. At Avaya's sole discretion, a "Named User" may be, without limitation, designated by name, corporate function (e.g., webmaster or helpdesk), an e-mail or voice mail account in the name of a person or corporate function, or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software.

Shrinkwrap License (SR). Customer may install and use the Software in accordance with the terms and conditions of the applicable license agreements, such as "shrinkwrap" or "clickthrough" license accompanying or applicable to the Software ("Shrinkwrap License"). (see "Third-party Components" for more information).

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or Hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without

the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third-party components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

Preventing Toll Fraud

"Toll fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud Intervention

If you suspect that you are being victimized by Toll Fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support Web site: <http://support.avaya.com>. Suspected security vulnerabilities with Avaya products should be reported to Avaya by sending mail to: securityalerts@avaya.com.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners, and "Linux" is a registered trademark of Linus Torvalds.

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support Web site: <http://support.avaya.com>.

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your Product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://support.avaya.com>.

Contents

Chapter 1: Installing the HP ProLiant DL360 G7 Server.....	7
HP DL360 G7 Server overview.....	7
How to use this document.....	7
Downloading HP documentation.....	7
HP DL360 document set.....	8
Front view of HP DL360 G7 Server.....	9
Back view of HP DL360 G7 Server.....	10
HP DL360 G7 Server specifications.....	11
HP DL360 G7 Server power specifications.....	12
HP DL360 G7 Server environmental specifications.....	12
HP DL360 G7 Server physical specifications.....	13
Installing the server in the rack.....	13
Index.....	17

Chapter 1: Installing the HP ProLiant DL360 G7 Server

HP DL360 G7 Server overview

The Avaya Common Servers category includes the HP ProLiant DL360 G7 1U server that supports several Avaya software solutions, some requiring additional hardware and memory requirements beyond the standard configuration. This book covers the standard configuration only—consult specific Avaya product documentation for application-specific or solution-specific server configurations.

How to use this document

This guide contains information for installing the HP DL360 Server as part of an Avaya deployment and provides:

- Instructions for how to find the appropriate online server documentation from HP.
- References to specific topics in standard HP documentation
- Suggested changes, details, and notes to assist the user in interpreting the manufacturer's documentation and to clarify Avaya's recommended implementation of the equipment
- Additional topics not covered in standard HP documentation but which are necessary for successful installation and maintenance of Avaya products

Downloading HP documentation

Use this procedure to find and download the HP ProLiant DL360 G7 documentation from HP.

Procedure

1. Open a browser and go to <http://www.hp.com/>.

2. Click on **Support and Drivers**.
 3. Select **See support and troubleshooting information** in the **Step 1** area.
 4. In the **Step 2** area of the page type **ProLiant DL360** in the **For product** field.
 5. Select **HP ProLiant DL360 G7 Server** series from the list of search results.
 6. Select **Manuals (guides, supplements, addendums, etc.)**.
 7. Download the document(s) listed in the *HP DL360 G7 document set > Documents to download* section below.
-

HP DL360 document set

Refer to the documents listed below for HP DL360 server information and procedures.

 Note:

Download the documents listed in the *Documents to download* section below. Printed copies of the documents listed in the *Documents included in the shipping container* section below ship with the server.

Documents to download

Abbreviation	Title	Part number
SI	Important Safety Information for Server Storage, Power, Networking, and Rack Products	No number
MSG	HP ProLiant DL360 G7 Server Maintenance and Service Guide	608339-003
TG	HP ProLiant Servers Troubleshooting Guide	375445-009
UG	HP ProLiant DL360 G7 Server User Guide	608341-003

 Note:

To locate an individual document::

- Go to <http://www.hp.com/>.
- Type **DL360 G7** plus the keywords of the document title in the **Search** field in the upper-right corner and press **Enter**.


Examples:

- Type **DL360 User Guide** to search for the *HP ProLiant DL360 G7 Server User Guide* document.
- Type **DL360 Maintenance Service** to search for the *HP ProLiant DL360 G7 Server Maintenance and Service Guide* document.

Documents included in the shipping container

Abbreviation	Title	Part number
1URH	1U Rack Hardware Installation Instructions	365 494-004
PCS	Power Cord Strain Relief Kit	407 454-021

Front view of HP DL360 G7 Server




Note:

Servers ship with 2–4 hard disk drives, depending upon product requirements.

No.	Description
1	Not present
2	Not present
3	DVD-RW
4	HP Systems Insight Display
5	Front USB connector
6	Video connector
7	Hard drive bay 4
8	Hard drive bay 3
9	Hard drive bay 2
10	Hard drive bay 1

Back view of HP DL360 G7 Server



No.	Description
1	Slot 1 PCIe2 x8 (8, 4, 2, 1) * Note: Servers might ship with a PCI card installed, depending upon product requirements.
2	Slot 2 PCIe2 x16 (16, 8, 4, 2, 1), 75W +EXT 75W* * Note: Servers might ship with a PCI card installed, depending upon product requirements.
3	Power supply bay 1 (populated)
4	Power supply bay 2
5	iLO 3 connector
6	Serial connector
7	Video connector
8	NIC 4 connector
9	NIC 3 connector
10	NIC 2 connector
11	NIC 1 connector
12	USB connectors (2)

*This expansion slot provides 75 W of power to an adapter, with an additional 75 W of power supplied by external power.

HP DL360 G7 Server specifications

Base unit	Baseline	Options
DL360 G7	1U chassis, dual socket	No additional options supported.
Processor	Intel E5620 Quad Core /2.4 GHz (Westmere) 3 memory channels per CPU with up to 3 RDIMMs per channel (most applications use 1 or 2 RDIMMs per channel to optimize memory speed)	• Intel X5670 six Core/2.93 GHz (Westmere) • Upgradable to dual processors for either E5620 or X5670
Memory	2 GB DDR3 RDIMMs (1333 MHz)	4 GB DDR3 RDIMMs (1333 MHz)
HW RAID 1	P410i RAID controller with 256MB cache and battery backup. Optioned as RAID 1 or 5	N/A
Hot-Plug disk drive cage	4 Small Form Factor 2.5" hot-plug hard drives bays are available when an optical drive is installed.	HP offers servers with 8 drive bays that do not support an optical drive (not supported by Avaya).
Disk drive	146GB SAS 2.5" 10K RPM 6G DP Hard Drive. Two base configurations: • 136 total: RAID 1, 2 x 146GB drives • 272 total: RAID 5, 3 x 146GB drives	Options: • Additional 146GB 10K RPM drive (4 max. with optical drive) • High performance 146GB 15K drives • 300GB 10K HDD
NICs	4 integrated ENET Gigabit NIC ports with TCP offload engine (included on motherboard)	HP NC382T PCI Express Dual Port Gigabit NIC expansion card (Broadcom 5709 silicon)
PCI slots	Two PCI-Express Gen 2 expansion slots: (1) full-length, full-height slot and (1) low-profile slot (1-FL/FH x 16 PCIe & 1-LP x 8 PCIe Riser	Meeting Exchange Recording uses a PCI-X riser in place of the low profile PCIe riser in the standard server.
Removable media	Slim line SATA DVD-RW optical drive (used in all Avaya configurations)	No additional options supported.
Power supply	460 W hotplug AC power supply	• 750W AC power supply • 1200W DC power supply • Single and dual power supply configurations

Base unit	Baseline	Options
Fans	3 fan modules (fan redundancy standard)	No additional options supported.
Additional items	1 front USB, 2 back USB, 1 internal USB	

HP DL360 G7 Server power specifications

Specification	Value
BTU	1794
Voltage	120 VAC
Plug Type	NEMA 5–15P
Circuit Breaker	15 amp
Pole	1
AMP Draw	5.5

HP DL360 G7 Server environmental specifications

Specification	Value
Temperature range	 Note: All temperature ratings shown are for sea level. An altitude derating of 1°C per 300 m (1.8° per 1,000 ft.) to 3048 m (10,000 ft.) is applicable. No direct sunlight allowed.
Operating	10°C to 35°C (50°F to 95°F)
Shipping	-40°C to 70°C (-40°F to 158°F)
Maximum wet bulb temperature	28°C (82.4°F)
Relative humidity (noncondensing)	 Note: Storage maximum humidity of 95% is based on a maximum temperature of 45° C (113°F). Altitude maximum for storage corresponds to a pressure minimum of 70 kPa.

Specification	Value
Operating	10% to 90%
Non-operating	5% to 95%

HP DL360 G7 Server physical specifications

Type	Description
Dimensions	Height: 4.32 cm (1.70 in)
	Width: 42.62 cm (16.78 in)
	Depth: 69.53 cm (27.38 in)
Weight (maximum; two processors, two power supplies, eight hard disk drives)	15.97 kg (35.20 lb)
Weight (minimum; one processor, one power supply, no hard drives)	14.51 kg (32.00 lb)
Weight (no drives installed)	14.06 kg (31.00 lb)

Installing the server in the rack

This installation checklist contains the principle steps that are necessary to install the server in the rack. Each task refers to an existing HP document and the topic title(s) that contains the step-by-step procedures. Where applicable, additional information and clarifications appear in the *Avaya recommendation* column. Perform each task in the order specified.



Note:

Although not used frequently, Avaya customers are required to have a monitor, keyboard, and mouse available for use by servicing technicians.

No.	Task	Reference	Avaya recommendation	✓
1	Observe safety warnings	ISI UG: <i>Rack warnings</i>		

No.	Task	Reference	Avaya recommendation	✓
2	Examine contents of shipping container (Avaya provided equipment)	UG: <i>Contents of the server shipping carton</i>	Ensure that the 6-digit material code on the order matches the 6-digit material code on the shipping container.	
3	Verify that the rack is installed according to the manufacturer's instructions and in accordance with all local codes and laws			
4	Examine installation environment (customer provided equipment)	UG: <i>Optimum environment</i>		
5	Verify that the rack is grounded in accordance with local electrical code.	UG: <i>Electrical grounding requirements</i>		
6	Remove the cabinet doors, if necessary.			
7	Attach the rails to the rack.		The rails included with the server will accommodate most square-hole racks. If these rails do not fit the rack, the customer must provide rails or a shelf for rack installation. Also, the rails included with the server might not work with round-hole racks, in which case the customer can obtain rails and/or a shelf from any distributor, for example http://www.racksolutions.com/ . The customer-provided rails and rack must be on site prior to the first day of installation.	

No.	Task	Reference	Avaya recommendation	✓
			 Note: The customer is responsible for any rack screws.	
8	Attach the server to the rack.	UG: <i>Installing the server into the rack</i>		
9	(Optional) Install the cable management arm.			
10	Connect the power cord(s).	SP: <i>Connecting the power cord to the power supply</i> UG: <i>Powering up and configuring the server</i>		
11	Power up the server.	UG: <i>Powering up and configuring the server</i>		

Index

C

checklist	13
installation	13

D

documentation	7 , 8
document set	8
downloading	7
how to use this document	7

H

HP DL360 G7	11
-------------------	--------------------

baseline specifications, configuration, and options	11
HP DL360 G7 Server	9 , 10 , 12 , 13
back view	10
electrical specifications	12
environmental specifications	12
front view	9
physical specifications	13
power specifications	12
HP DL360 G7 Server overview	7

